


## Connected – No Splitter



Status

- Device Status
- MoCA Link Rates

Settings

- MoCA settings
- Device settings
- Security settings

Advanced

- Upgrade
- Restore
- Reboot


### Device Status

DEVICE STATUS

The following display shows the current status and settings.

DEVICE STATUS

SOC Version: MXL371x.1.15.7  
My MoCA Version: 2.5  
Network MoCA Version: 2.5  
IP Address: 192.168.254.254  
MAC Address: 94:cc:04:10:ba:ec  
Link Status: Up  
Beacon Channel: 1150  
Primary Channel: 1175  
Secondary Channel: 1300  
First Channel: 1175  
Number of Channels: 5  
Ethernet TX: Tx Good: 596  
Tx Bad: 0  
Tx Dropped: 0  
Ethernet RX: Rx Good: 434  
Rx Bad: 0  
Rx Dropped: 0



Status

- Device Status
- MoCA Link Rates

Settings

- MoCA settings
- Device settings
- Security settings

Advanced

- Upgrade
- Restore
- Reboot

### PHY RATES

The following table shows the PHY rate in Megabits per second (Mbps) between coax bridges on the network.  
**NOTE:** Either NPER or VLPER will be displayed for MoCA 2.5 nodes based on value of boot config parameter "txprioritytype".

PHY RATES

Type: ☒ Unicast NPER ☐ Unicast VLPER

From/To	0	1
0	329	579
1	604	328


**Legend**

MoCA 2.5	MoCA 2.0	MoCA 1.x	GCD
----------	----------	----------	-----

Refresh

[Contact goCoax Customer Support](#)

Not connected – Splitter Used



Status

[Device Status](#)

[MoCA Link Rates](#)

Settings

[MoCA settings](#)

[Device settings](#)

[Security settings](#)

Advanced

[Upgrade](#)

[Restore](#)

[Reboot](#)


## Device Status

**DEVICE STATUS**

The following display shows the current status and settings.

**DEVICE STATUS**

**SOC Version:** MXL371x.1.15.7  
**My MoCA Version:** 2.5  
**Network MoCA Version:** 2.5  
**IP Address:** 192.168.254.254  
**MAC Address:** 94:cc:04:10:ba:ec  
**Link Status:** Down  
**Beacon Channel:** 1600  
**Primary Channel:** 1600  
**Secondary Channel:** 0  
**First Channel:** 1175  
**Number of Channels:** 5  
**Ethernet TX:** Tx Good: 0  
Tx Bad: 0  
Tx Dropped: 0  
**Ethernet RX:** Rx Good: 0  
Rx Bad: 0  
Rx Dropped: 0



Status

[Device Status](#)

[MoCA Link Rates](#)

Settings

[MoCA settings](#)

[Device settings](#)

[Security settings](#)

Advanced

[Upgrade](#)

[Restore](#)

[Reboot](#)

## PHY Rates

**PHY RATES**

The following table shows the PHY rate in Megabits per second (Mbps) between coax bridges on the network.  
**NOTE:** Either NPER or VLPER will be displayed for MoCA 2.5 nodes based on value of boot config parameter "txprioritytype".

**PHY RATES**

Type: ☒ Unicast NPER ☐ Unicast VLPER

From/To

**Legend**

MoCA 2.5

MoCA 2.0

MoCA 1.x

GCD

Refresh

[Contact goCoax Customer Support](#)